



1 FLOOR PREPARATION

- Measure the foundation or crown-hole according to the bicycle-stand width
- Bicycle-stand feet are inserted in the middle of the foundation
- Create the \varnothing foundation approx. 100 mm wide
- The drilling depth should be at least 300mm

2 BICYCLE-STAND CONCRETING

- Concrete class should be selected depending on the substrate and specifications so that ideal durability is guaranteed

